Connecting with DJI



Connecting with Vista



Connecting with X8 (Need CLI)



HDZero Wiring



Wiring schematic diagram